



Keyboard care and basic maintenance

Guidance for Parents/Carers

With children not being able to see their regular music teacher we have put together a guide to help with understanding basic instrument care.

If you are in contact with the music teacher, they will also be able to help and advise you if you have any questions.

When the instrument isn't being used

- Care should be taken when placing the instrument back in its case.
- Do not subject the instrument to extremes of temperature e.g. near radiators, in hot cars, very cold places, as this can damage the instrument.
- Always keep the instrument in its case when it's not being played to stop it from getting damaged.
- Make sure the case is securely fastened when you are transporting it.

Cleaning

- The keyboard should be cleaned regularly with a duster to remove any dirt or grease from the keys or controls.
- Do not let any water get onto or into the keyboard, as this can damage the instrument.
- When dirt is noticeable you can dampen a cloth in a dilute solution of a neutral detergent, wring out well, and use this cloth to wipe away the dirt.

General Care

- Take care when connecting the instrument to the electricity supply, or make sure to use the correct batteries.
- If the power supply doesn't work, you can try batteries to see if it's the power supply or the keyboard that's faulty.
- Make sure that you connect up any cables correctly, including the mains adapter and headphones if necessary.

Remember: If headphones are being used, check that the volume hasn't been set too loud before they're put on.

If you have any other questions or a setting seems to have changed, you can usually find the manual online for your particular make and model (which you will find on a label usually on the bottom of the keyboard).